

AIRCRAFT PARKING / DOCKING CHART- ICAO


13 41 09 N
100 44 56 E

APRON ELEV
1.8 m (5.9 ft)

TWR FREQ 119.0 (RWY 19R/01L)
TWR FREQ 118.2 (RWY 19L/01R)

GND FREQ 121.95 (WEST APRON)
GND FREQ 121.75 (MAIN APRON)
GND FREQ 121.65 (EAST APRON)


BANGKOK/Suvarnabhumi Intl



- TAXIWAYS ASPH PCN 137/F/D/XT
- APRONS CONC PCN 126/R/D/XT
- INS COORDINATES FOR AIRCRAFT STANDS SEE AIRCRAFT PARKING/DOCKING CHART - ICAO VERSO 1,2 AND 3
- AIRCRAFT STAND VISUAL DOCKING GUIDANCE SYSTEM SEE VTBS AD 2.9

Remark : Transfer Baggage Terminal - TBT

LEGEND	
AERODROME REFERENCE POINT (ARP) 13 41 09 N 100 44 56 E	
BUILDING OR LARGE STRUCTURE	
TAXI ROUTES	
AIRCRAFT STAND AND IDENTIFICATION	or
HOLDING POSITION	
TAXIWAY IDENTIFICATION	B or B12
CONCOURSE	
CLOSED	
HOT SPOT	HS
TOWING STOPLINE (3 m x 0.8 m)	



CHANGE : EDITORIAL