

AIRCRAFT PARKING / DOCKING CHART - ICAO


13 41 09 N
100 44 56 E

APRON ELEV
5.9 FT

TWR FREQ 119.0 (RWY 19R/01L)
TWR FREQ 118.2 (RWY 19L/01R)

GND FREQ 121.95 (WEST APRON)
GND FREQ 121.75 (MAIN APRON)
GND FREQ 121.65 (EAST APRON)

BANGKOK / Suvarnabhumi Intl




MAG VAR 0° 35' W (2016)
ANNUAL CHANGE 0° 0' E

- TAXIWAYS ASPH PCN 137/F/D/X/T
- APRONS CONC PCN 126/R/D/X/T
- INS COORDINATES FOR AIRCRAFT PARKING/DOCKING CHART - ICAO VERSO 1,2 AND 3
- AIRCRAFT STAND VISUAL DOCKING GUIDANCE SYSTEM SEE VTBS AD 2.9

Remark : Transfer Baggage Terminal - TBT

LEGEND	
AERODROME REFERENCE POINT (ARP) 13 41 09 N 100 44 56 E	
BUILDING OR LARGE STRUCTURE	
TAXI ROUTES	
AIRCRAFT STAND AND IDENTIFICATION	or
HOLDING POSITION	
TAXIWAY IDENTIFICATION	B or B12
CONCOURSE	
CLOSED	
HOT SPOT	HS
TOWING STOPLINE (3 m x 0.8 m)	



CHANGE : REVISED CHART.

GROUND RUN-UP ENCLOSURE (GRE)