

**STANDARD DEPARTURE CHART-
INSTRUMENT (SID) - ICAO**

**BANGKOK/Suvarnabhumi Intl (VTBS)
RNAV RWY01L**

ALBOS3H BONVO3H
NOBER3H NUNLI3H PASTO3H
ROBKA3H SEMBO3H TANGO3H
TARED3H TL3H UPKUP3H

TABULAR DESCRIPTION (1)

RNAV RWY01L											
Serial Number	Path Descriptor	Waypoint Identifier	Flyover	Course ° M (° T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KT)	VPA/TCH	Navigation Specification
ALBOS3H TO R474											
010	-	DER RWY01L	-	-	+0.58	-	-	-	-	-	RNAV 1
020	CF	VARIS	Y	015°(014.4°)	+0.58	3.5	R	-	-230	-	RNAV 1
030	DF	BS104	-	-	+0.58	-	-	-	-	-	RNAV 1
040	TF	BS105	-	015°(014.3°)	+0.58	22.0	-	-	-	-	RNAV 1
050	TF	BS106	-	015°(014.3°)	+0.58	9.5	-	+FL160	-	-	RNAV 1
060	TF	ALBOS	-	015°(014.3°)	+0.58	17.7	-	-	-	-	RNAV 1
BONVO3H TO M502											
010	-	DER RWY01L	-	-	+0.58	-	-	-	-	-	RNAV 1
020	CF	VARIS	Y	015°(014.4°)	+0.58	3.5	R	-	-230	-	RNAV 1
030	DF	BS104	-	-	+0.58	-	-	-	-	-	RNAV 1
040	TF	BS108	-	315°(314.9°)	+0.58	10.0	L	-10000 ; +8000	-	-	RNAV 1
050	TF	BS117	-	279°(278.8°)	+0.58	10.2	-	+11000	-	-	RNAV 1
060	TF	BS118	-	279°(278.9°)	+0.58	10.6	L	+FL140	-	-	RNAV 1
070	TF	OBMAR	-	244°(243.2°)	+0.58	18.3	L	+FL160	-	-	RNAV 1
080	TF	BONVO	-	230°(229.8°)	+0.58	22.7	-	-	-	-	RNAV 1
NOBER3H TO B346, W21											
010	-	DER RWY01L	-	-	+0.58	-	-	-	-	-	RNAV 1
020	CF	VARIS	Y	015°(014.4°)	+0.58	3.5	R	-	-230	-	RNAV 1
030	DF	BS104	-	-	+0.58	-	-	-	-	-	RNAV 1
040	TF	BS105	-	015°(014.3°)	+0.58	22.0	L	-	-	-	RNAV 1
050	TF	BS107	-	286°(285.1°)	+0.58	15.7	-	-FL150 ; +FL140	-	-	RNAV 1
060	TF	DISCO	-	286°(285.0°)	+0.58	23.0	R	-	-	-	RNAV 1
070	TF	TANGO	-	353°(352.0°)	+0.58	12.2	R	-	-	-	RNAV 1
080	TF	NOBER	-	035°(034.4°)	+0.58	43.7	-	-	-	-	RNAV 1