

**STANDARD DEPARTURE CHART -  
INSTRUMENT (SID) - ICAO**

**BANGKOK/Suvarnabhumi Intl (VTBS)  
RNAV RWY19**

ALBOS1J BONVO1J BUT1J DOSBU1J  
GOMES1J HHN1J KASNI1J LIPLI1J  
NOBER2J NUNLI1J OLVUK1J PASTO1J  
REGOS1J RIVDU1J RYN1J SELKA1J  
SEMBO2J TARED1J UKERA1J VANKO1J

**TABULAR DESCRIPTION (1)**

RNAV RWY19											
Serial Number	Path Descriptor	Waypoint Identifier	Flyover	Course ° M (° T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KT)	VPA/TCH	Navigation Specification
ALBOS1J TO R474											
010	-	DER RWY19	-	-	+ 0.6	-	-	-	-	-	RNAV 1
020	VA	-	-	195°(194.4°)	+ 0.6	-	-	+700	-	-	RNAV 1
030	DF	BS920	Y	-	+ 0.6	-	L	-	-220	-	RNAV 1
040	TF	BS924	-	165°(164.4°)	+ 0.6	7.6	-	-	-	-	RNAV 1
050	TF	BS927	-	195°(194.3°)	+ 0.6	4.0	-	-	-	-	RNAV 1
060	TF	BS931	-	285°(284.3°)	+ 0.6	12.2	-	-	-	-	RNAV 1
070	TF	BS932	-	002°(001.5°)	+ 0.6	5.1	-	-	-	-	RNAV 1
080	TF	GUGOT	-	002°(001.5°)	+ 0.6	6.4	-	-10000	-	-	RNAV 1
090	TF	BS933	-	041°(039.9°)	+ 0.6	7.2	-	-	-	-	RNAV 1
100	TF	BS934	-	041°(039.9°)	+ 0.6	7.2	-	-	-	-	RNAV 1
110	TF	BS935	-	015°(014.2°)	+ 0.6	29.1	-	-	-	-	RNAV 1
120	TF	ALBOS	-	022°(021.6°)	+ 0.6	27.4	-	-	-	-	RNAV 1
BONVO1J TO M502											
010	-	DER RWY19	-	-	+ 0.6	-	-	-	-	-	RNAV 1
020	VA	-	-	195°(194.4°)	+ 0.6	-	-	+700	-	-	RNAV 1
030	DF	BS920	Y	-	+ 0.6	-	L	-	-220	-	RNAV 1
040	TF	BS924	-	165°(164.4°)	+ 0.6	7.6	-	-	-	-	RNAV 1
050	TF	BS927	-	195°(194.3°)	+ 0.6	4.0	-	-	-	-	RNAV 1
060	TF	BS931	-	285°(284.3°)	+ 0.6	12.2	-	-	-	-	RNAV 1
070	TF	BS932	-	002°(001.5°)	+ 0.6	5.1	-	-	-	-	RNAV 1
080	TF	GUGOT	-	002°(001.5°)	+ 0.6	6.4	-	-10000	-	-	RNAV 1
090	TF	BS936	-	002°(001.5°)	+ 0.6	6.9	-	-	-	-	RNAV 1
100	TF	KABUT	-	329°(328.4°)	+ 0.6	11.5	-	+FL140	-	-	RNAV 1
110	TF	BS937	-	279°(278.3°)	+ 0.6	13.7	-	-	-	-	RNAV 1
120	TF	OBMAR	-	273°(272.2°)	+ 0.6	10.3	-	-	-	-	RNAV 1
130	TF	BONVO	-	231°(229.8°)	+ 0.6	22.7	-	-	-	-	RNAV 1