

**AIRCRAFT PARKING / DOCKING CHART-ICAO**


13 41 09 N  
100 44 56 E

APRON ELEV 4 FT

TWR FREQ 118.2 ( RWY 19 / 01 )  
TWR FREQ 119.0 ( RWY 20L / 02R , 20R / 02L )

GND FREQ 121.65 , 121.7 , 121.75 , 121.95


BANGKOK / Suvarnabhumi Intl



LEGEND	
AERODROME REFERENCE POINT ( ARP ) 13 41 09 N 100 44 56 E	
BUILDING OR LARGE STRUCTURE	
CONSTRUCTION AREA	
AIRCRAFT STAND AND IDENTIFICATION or	
RUNWAY-HOLDING POSITION	
TAXIWAY IDENTIFICATION	
CONCOURSE	
CLOSED	
HOT SPOT SEE VTBS AD 2.20 LOCAL AERODROME REGULATIONS ITEM 11	
TOWING STOPLINE	
ENGINE RUN-UP AREA SEE VTBS AD 2.20 LOCAL AERODROME REGULATIONS ITEM 12.2	
SWING COMPASS AREA CONDITION OF USE : SWING COMPASS ACTIVITY IS PERMITTED ONLY WHEN RUNWAY 01/19 IS CLOSED.	

REMARKS :

- TAXIWAYS ASPH PCR 1730/F/D/X/T , 870/F/C/X/T
- TAXIWAYS CONC PCR 1660/R/D/W/T , 1220/R/C/W/T , 900/R/A/W/T
- MAIN / EAST / WEST APRON CONC PCR 1360/R/D/W/T
- SAT-1 APRON CONC PCR 1010/R/A/W/T
- INS COORDINATES FOR AIRCRAFT STANDS SEE AIRCRAFT PARKING/DOCKING CHART-ICAO ( VERSOS )
- AIRCRAFT STAND VISUAL DOCKING GUIDANCE SYSTEM SEE VTBS AD 2.9
- TAXILANES T8 , T9 , T10 , T11 AND T12 ARE ABLE TO ACCOMMODATE AIRCRAFT UP TO CODE E ( WINGSPAN LESS THAN 65 m )



CHANGE : REVISED CHART